

Power bank 2300 mAh black FOREVER PB-009

Universal external battery Forever is a convenient and practical product for recharging your mobile phone or tablet anywhere, at home, at work or on the way without having to connect to the mains. The capacity of the present power of the bank is 2300 mAh, which will allow to fully charge the battery on your smartphone.

Technical description

Capacity	2300 mAh
Colour	black
Input voltage	DC 5 V - 1 A
Line	Energy line
Output voltage	DC 5 V - 1 A
Package	box
Producer	Forever
Type of connector	micro USB



Compatibility

Telefony: LG

A130 \ A155 \ A160 \ Apex \ Axis \ BL20 New Chocolate \ BL40 New Chocolate \ C105 \ C310 \ C320
 InTouch Lady \ C900 Optimus 7Q \ Cookie 3G T320 \ Cookie Lite T300 \ Cookie Style T310 \ Cookie WiFi
 T310i \ Cosmos Touch VN270 \ E900 Optimus 7 \ GB102 \ GB130 \ GB250 \ GC900 Viewty Smart \
 GD510 Pop \ GD550 Pure \ GD900 Crystal \ GM310 \ GM730 Eigen \ GM750 \ GS290 Cookie Fresh \
 GS390 Prime \ GT500 Puccini \ GT505 \ GT550 Encore \ GU292 \ GW300 \ GW370 Rumour Plus \
 GW520 \ GW550 \ GW620 \ GW910 \ HB620T \ KC550 \ KE360 \ KE500 \ KE520 \ KE590 \ KE800 \
 KE820 \ KE850 Prada \ KE970 Shine \ KF310 \ KF510 \ KF600 \ KF700 \ KF750 Secret \ KF757 Secret \
 KG250 \ KG275 \ KG280 \ KG285 \ KG320 \ KG375 \ KG800 \ KG810 \ KM380 \ KM500 \ KP100 \ KP130 \
 KP230 \ KS10 \ KS20 \ KT520 \ KT770 \ KU250 \ KU311 \ KU380 \ KU450 \ KU580 \ KU800 \ KU950 \
 KU990 Viewty \ L600v \ Octane \ Optimus 2X \ Optimus 3D P920 \ Optimus Big LU6800 \ Optimus Black
 P970 \ Optimus Chat C550 \ Optimus Chic E720 \ Optimus M \ Optimus Mach LU3000 \ Optimus Me P350
 \ Optimus One P500 \ Optimus Pad \ Optimus Q \ Optimus S \ Optimus T \ Optimus Z \ Phoenix \ Quantum
 \ Revolution \ S310 \ SU420 Cafe \ SU920 \ T315 \ Thrill 4G \ Thrive \ Town C300 \ Vortex VS660 \ Xenon
 GR500

Telefony: Motorola

A1200 \ A1260 \ A1680 \ A910 \ BACKFLIP \ BRAVO MB520 \ CHARM \ CITRUS WX445 \ Cliq 2 \ CUPE \ DEFY \ DROID 2 \ DROID 2 Global
 \ DROID BIONIC \ DROID PRO XT610 \ DROID X \ DROID X ME811 \ ES400 \ EX112 \ EX115 \ EX201 \ EX210 \ Flipout \ FLIPSIDE MB508 \
 GLEAM \ Grasp WX404 \ KRZR K1 \ KRZR K3 \ L6 \ MILESTONE \ MILESTONE 2 \ MILESTONE XT720 \ MOTO MT716 \ MOTOTV EX245 \
 MT810ix \ PEBL U6 \ Q 9h \ QUENCH \ Quench XT3 XT502 \ RAZR maxx V6 \ RAZR V3 \ RAZR V3i \ RAZR V3xx \ RAZR2 V8 \ RAZR2 V9 \
 RAZR2 V9x \ RIZR Z3 \ RIZR Z8 \ ROKR E6 \ ROKR E8 \ SLVR L7e \ SPICE XT300 \ U9 \ V1100 \ V235 \ V360 \ V3x \ W375 \ W380 \ W510 \
 XPRT \ XT301 \ XT806 \ XT810 \ Z6c \ Z6w

Telefony: Nokia

200 Asha \ 201 Asha \ 202 Asha \ 203 Asha \ 300 Asha \ 302 Asha \ 303 Asha \ 3710 fold \ 5630 XpressMusic \ 610 Lumia \ 6500 classic \
 6600i slide \ 6700 classic \ 6710 Navigator \ 6730 classic \ 710 Lumia \ 7900 Crystal Prism \ 7900 Prism \ 800 Lumia \ 808 Lumia \ 8600 Luna \
 8800 Arte \ 8800 Carbon Arte \ 8800 Gold Arte \ 8800 Sapphire Arte \ 900 Lumia \ C3-01 Touch and Type \ C5 \ C5 TD-SCDMA \ C5-03 \
 C6-01 \ E52 \ E55 \ E6 \ E7 \ E72 \ E75 \ N8 \ N85 \ N86 8MP \ N9 \ N900 \ N97 \ N97 mini \ X2 \ X2-01 \ X3 \ X3-02 Touch and Type \ X7-00

Telefony: Samsung

B100 \ B130 \ B2100 Solid \ B220 \ B2700 Solid \ B2710 \ B300 \ B3210 CorbyTXT \ B3310 \ B3410 \ B3410W Ch@t \ B520 \ B5310 CorbyPro
 \ B5722 \ B6520 Omnia PRO 5 \ B6610 \ B7300 OmniaLITE \ B7330 OmniaPRO \ B7350 Omnia PRO 4 \ B7510 Galaxy Pro \ B7610
 OmniaPRO \ B7620 Giorgio Armani \ B7722 \ C180 \ C270 \ C3010 \ C3050 Stratus \ C3060R \ C3200 Monte Bar \ C3222 Ch@t 322 \ C3300
 Champ \ C3500 Ch@t 350 \ C3510 Genoa \ C3522 \ C3630 \ C3750 \ C450 \ C5010 Squash \ C5110 \ C5130 \ C5510 \ C6620 \ C6625 \ D780
 flip \ D880 Duos \ D980 \ E1050 \ E1052F \ E1055T \ E1070 \ E1080 \ E1100 \ E1105F \ E1107 Crest Solar \ E1120 \ E1130B \ E1150 \ E1151
 \ E1170 \ E1172 \ E1225 Dual Sim Shift \ E1252 \ E1310 \ E1360 \ E210 \ E2100B \ E2120 \ E2121B \ E2152 \ E2210B \ E2230 \ E2330 \



E2370 \ E2510 \ E2530 \ E2550 \ E2652W Champ Duos \ E3010 \ E3210 \ F110 \ F200 \ F210 \ F250 \ F330 \ F400 \ F480 \ F490 \ F700 \ G400 Soul \ G600 \ G800 \ G810 \ i200 \ i450 \ i550 \ I5500 Galaxy 550 \ I5510 Galaxy 551 \ i560 \ I5700 Galaxy Spica \ I5800 Galaxy 3 \ I5801 Galaxy Apollo \ I6410 \ i7110 \ I7500 Galaxy \ i780 \ I8000 Omnia II \ I8320 \ I8330 \ i8510 INNOV8 \ I8520 Galaxy Beam \ I8700 Omnia 7 \ i8910 Omnia HD \ i900 Omnia \ I9000 Galaxy S \ I9001 Galaxy S Plus \ I9003 Galaxy SL \ I9010 Galaxy S Giorgio Armani \ i9020 Nexus S \ I9070 Galaxy S Advance \ I9100 Galaxy S II \ I9300 Galaxy S III \ J150 \ J200 \ J210 \ J400 \ J630 \ J700 \ J750 \ J770 \ J800 Luxe \ L170 \ L310 \ L600 \ L700 \ L760 \ L770 \ L810v Steel \ L870 \ M110 \ M150 \ M200 \ M2510 \ M2520 Beat Techno \ M2710 Beat Twist \ M310 \ M3200 Beat s \ M3310 \ M3510 Beat b \ M600 \ M610 \ M6710 Beat DISC \ M7500 Emporio Armani \ M7600 Beat DJ \ M8800 Pixon \ M8910 Pixon12 \ N7000 Galaxy Note \ P180 \ P260 \ P520 \ P720 \ P960 \ S3030 Tobi \ S3100 \ S3110 \ S3310 \ S3320 \ S3350 Ch@t 335 \ S3370 \ S3500 \ S3600 \ S3650 Corby \ S3850 Corby II \ S5010 \ S5050 \ S5150 Diva folder \ S5200 \ S5210 \ S5230 Star \ S5233T \ S5250 Wave 525 \ S5260 Star II \ S5300 Galaxy Pocket \ S5310 Corby Pro \ S5330 Wave 533 \ S5350 Shark \ S5500 Eco \ S5503 \ S5510 \ S5530 \ S5550 Shark 2 \ S5560 Marvel \ S5570 Galaxy Mini \ S5600 Preston \ S5620 Monte \ S5660 Galaxy Gio \ S5670 Galaxy Fit \ S5750 Wave575 \ S5780 Wave 578 \ S5830 Galaxy Ace \ S7070 Diva \ S7200 \ S7220 Ultra b \ S7230E Wave 723 \ S7330 \ S7350 Ultra s \ S7510 \ S7550 Blue Earth \ S8000 Jet \ S8300 UltraTOUCH \ S8500 Wave \ S8530 Wave II \ U200 \ U800 Soul b \ U900 Soul

Telephony: Sony Ericsson

J108i Cedar \ M1i Aspen \ U5i Vivaz \ U8i Vivaz Pro \ W100 Spiro \ W150 Yendo \ X10 Xperia \ X10
Xperia Mini \ X10 Xperia Mini Pro \ X12 Xperia Arc \ X2 Xperia \ X8 Xperia \ Xperia Arc S \ Xperia Neo \
Xperia Neo V \ Xperia Play \ Xperia Play CDMA \ Xperia Pro